


My personal Perseus Client Settings



Client Nickname	DD3KF
City/Country	Aachen, Germany
Client UDP Port	8014
Longitude	6.159569 (+/- xxx.dxxxxx)
Latitude	50.749439 (+/- xx.dxxxxx)

Please see first the instructions delivered with the program.

Nickname:

I use my HAM Radio call sign.

City/Country

Please fill in your location!

Longitude / Latitude

You have to use the decimal value of your geographical coordination. To find them use <http://itouchmap.com/latlong.html>

Firewall Setting

To allow access to a remote receiver you have to open the port 8014 **UDP** in your firewall.

I am using a Fritz!Box DSL router which is very popular in Germany. To open the proper ports I use the http://www.avm.de/de/Service/FAQs/FAQ_Sammlung/14047.php3 (found only a German version). Maybe for your router there are similar programs.

Maybe you have to open also your software firewall, for example the windows firewall.

In case of problems you will find more information in http://groups.yahoo.com/group/perseus_SDR/